

End A	End B	End C	Part #	
BNC Jack	BNC Plug	BNC Jack	BNC-3374	
BNC Jack	BNC Plug	BNC Jack	BNC-3374-75	
BNC Jack	BNC Plug	BNC Jack	BNC-3374-SJ	
BNC Jack	BNC Jack	BNC Jack	BNC-3375	
BNC Jack	BNC Jack	BNC Jack	BNC-3375-75	
BNC Jack	BNC Plug	BNC Jack	BNC-3874	
BNC Jack	BNC Plug	BNC Jack	BNC-7366	
BNC Jack	BNC Plug	BNC Jack	BNC-7366-75	
BNC Jack	BNC Plug	BNC Jack	BNC-7367	
BNC Plug	BNC Jack	BNC Jack	BNC-7368	
BNC Plug	BNC Jack	BNC Jack	BNC-7369	
BNC Jack	BNC Plug	BNC Jack	BNC-7374	
BNC Jack	BNC Jack	BNC Jack	BNC-7375	
BNC Plug	BNC Plug	BNC Plug	BNC-7376	
MU Jack	MU Jack	MU Jack	MU-7236	
MU Jack	MU Plug	MU Jack	MU-7237	
RFF Jack	RFF Jack	RFF Jack	RFF-7773-3GH	

End A	End B	End C	Part #	
RFN Jack	RFN Jack	RFN Jack	RFN-7656	
RFN Jack	RFN Plug	RFN Jack	RFN-7659	
SMA Jack	SMA Plug	SMA Jack	SMA-2594	
SMA Jack	SMA Jack	SMA Jack	SMA-2775	
TNC Jack	TNC Plug	TNC Jack	TNC-7474	
TWX Jack	TWX Jack	TWX Jack	TWX-7509	
TWX Jack	TWX Plug	TWX Jack	TWX-3510	
UHF Jack	UHF Jack	UHF Jack	UHF-7623	
UHF Jack	UHF Plug	UHF Jack	UHF-7624	